

# STUDY ON THE THERMAL DEGRADATION OF A MIXTURE OF A NOVEL CAGED BICYCLIC PHOSPHATE AND AMMONIUM POLYPHOSPHATE

Jianwei Hao<sup>1\*</sup>, Weizhong Jiang<sup>1</sup>, Zhidong Han<sup>2</sup>

<sup>1</sup>*National Laboratory of Flame Retardant Materials, School of Materials, Beijing Institute of Technology, 5 south Zhongguancun Street, Haidian District, Beijing 100081, P. R. China  
(email.address, [hjw@bit.edu.cn](mailto:hjw@bit.edu.cn))*

<sup>2</sup>*School of Materials Science and Engineering, Harbin University of Science and Technology, Harbin 150040, People's Republic of china*

**Keywords:** Intumescent; Trimer; APP, Thermal degradation.

In order to understand the intumescent flame retardant effect of a novel caged bicyclic phosphate (Trimer, tri (1-oxo-2,6,7-trioxa-1-phosphabicyclo [2,2,2] octane-methyl) phosphate) and ammonium polyphosphate (APP) used in intumescent coatings [1] and some polymers such as polypropylene [2], the thermal degradation of Trimer, APP and their mixture were studied.

Different degradation behavior of Trimer/APP (mass ratio of 2:1) from Trimer and APP was observed by thermogravimetric analysis (TG) shown in Fig.1. Trimer shows higher thermal stability, its first weight loss peak reached 43.2 %/min (30 % weight loss at 375 °C), and relative main gaseous products are hydrocarbon containing compounds. The experimental TG curve of Trimer/APP, compared with the theoretically calculated one, showed lower initial degradation temperature and higher char residue at 800 °C, demonstrating interactions of Trimer and APP during thermal degradation. Such interactions were evidenced by gaseous degradation products analyzed by TG-FTIR.

It is interesting that Trimer couldn't expand alone, but after mixed with APP expanded rapidly during about 365~420 °C (see Fig. 2) and with more P, O and N compounds being kept in condensed phase proved by X-ray photoelectron and spectroscopy (XPS) shown in Fig. 3. These results demonstrated the synergistic effect involving cross-linking reactions between Trimer and APP during the thermal degradation process. The synergistic main products of the char residue should be polyphosphate and its derivatives.




Fig. 1 TG (left and middle) and DTG (right) curves of APP, Trimer and Trimer/APP under N<sub>2</sub> atmosphere (20 °C/min)




Fig. 2 Digital pictures of Trimer (T) and Trimer/APP (TA) after thermal-oxidative degradation at different temperatures




Fig. 3 Comparison of P2p/C1s (a), O1s/C1s (b) ratios of Trimer and Trimer/APP, and N1s/C1s ratio of Trimer/APP (c) with temperature increased

## Reference

1. Haixu W, Jianwei H, et al. Proceedings of the 22nd Conference on Recent Advances in Flame Retardancy of Polymeric Materials, Stamford, CT, 2011.
2. Weizhong J, Jianwei H, Zhidong H, Polymer degradation and stability. 97:632-637, 2012.